

ATV120 TOWABLE FLAIL MOWER



MachinerieDB



OPERATION & PARTS MANUAL

Please read these instructions before using. Always grease all fittings and be sure to always check oil before operating! Retain this manual for future use.

www.machineriedb.com

819-350-5543 M-F 7am-4pm

1776 161 Rd, St Valere

INDEX				
Section:			Description:	Page No:
	1		Introduction	3
			HSE information sheet	4
	2		In the interest of safety: DO NOT	6
	3		In the interest of safety: DO	6
	4		Instruction & Warning Decals	7
	5		Operating Instructions And Adjustments	8
		5.1	Initial Check	8
		5.2	Drawbar Adjustment	9
		5.3	Mower Cutting Height	10
		5.4	Starting The Engine	10
		5.5	Forward Speed	11
		5.6	Stopping The Mower	11
		5.7	Transport Position	11
		5.8	Anti-scalping roller / Side skid's	12
	6		Maintenance Schedule	13
		6.1	Engine	13
		6.2	Excess Crop Build Up	13
		6.3	Visual Check	13
		6.4	tire Pressures	14
		6.5	Rotor Bearing Inspection	14
		6.6	Wheel Bearing Inspection	14
		6.7	Oil Coupling / Bush Wear	14
		6.8	General Inspection	14
		6.9	Rotor Flail Maintenance	14
	7		Parts List	16
	8		Warranty	28

1

INTRODUCTION

With the purchase of your FLAIL MOWER you have made an excellent choice.

This machine should give first class service for a long time, if used correctly, and maintained as described in this manual.

Fitted with an easy to start engine it has been designed to cope with a wide range of conditions. The AT Pull behind Flail mower incorporates easy height adjustment, range of engine options and a full width anti-scalping roller to avoid damage to machine and sward.

The mower is constructed from 4 mm steel for added strength; all fittings are of high quality to ensure years of trouble free use.

Selecting and using equipment for All Terrain Vehicles (ATV's)

Introduction

This information sheet gives advice to users on how to use all Terrain vehicles (ATV's) safely with towed and mounted equipment.

Plan the use of an ATV carefully and take particular note of ground conditions and slopes, as these may vary considerably, depending on the terrain, weather conditions, ground surface and the crop under the wheels.

Towed Equipment

Choose equipment which matches your ATV. Stability of towed equipment is affected by:

Weight Ratios

1. The safe ratio between the trailed loaded maximum weight and unloaded weight of the ATV must be assessed for each operation.
2. Always take note of information given in the manufacture's handbook when making this assessment.
3. As a guide research shows that on level ground, 4 x unloaded weight of the ATV for braked trailed equipment and 2 x unloaded weight of the ATV for un-braked trailed equipment are the appropriate maximum ratios.

Note: For work on slopes or uneven ground the ratio will need to be reduced.

Braking

Fit:

1. Brakes to trailed equipment. This helps prevent jack-knifing when braking or traveling downhill;
2. Over-run brakes which come into action whenever the ATV brakes are applied;
3. A manually operated parking brake operable from the driving position. This provides control for use when going up slopes.

Hitching and Loads

Stability is also improved if:

1. Some weight is transferred from the trailer onto the ATV draw-bar;
2. The draw-bar has a swivel hitch and the ATV a ball hitch having a large head to neck ratio. This makes it easier for the draw-bar hitch to swivel and cope with undulating ground;
3. The load is positioned as near to the center of the trailer as possible.

Tires and Wheels

1. Check tire pressures regularly with a pressure gauge capable of reading low pressures accurately;
2. Check tires regularly for damage and wear;
3. Select equipment which has tires and wheels that can cop with speeds over 20 mph and occasional higher speeds;
4. Use wheels with bead locks on the rims if the main use is going to be on sloping ground. This prevents tire run-off on side slopes.

Maximum Towed Weight

Follow the advice given by manufacturers on the maximum trailed weight. This will be found on the equipment or in the instruction handbook.

Note: Universal road going trailers will normally have the maximum gross weight stated on a separate notice.

Mounted Equipment

ATV's using mounted equipment are safer if the equipment has:

- a low center of gravity. This improves stability.
- a gross weight within the limits approved by ATV manufacturer.
- no dangerous projections to injure the operator or bystanders;
- no forward projections which stop head protection being worn;
- controls which are easy to work and which do not create a hazard to the operator;

Instructions for Mounted and Trailed Equipment

Take note of the manufacturer's instructions on:

- operating on slopes;
- where to place loads so as to give fore/aft and lateral stability;
- the risks of using equipment with negative drawbar nose weight, ie loss of traction;
- the maximum operating speed;
- the effect that equipment carried on front and/or rear racks will have on longitudinal and lateral stability;
- securing loads;
- the use of ballast, if any, to improve stability;
- the need to select and use safe routes.

Using an ATV

- Read the manufacturers's instruction book and take note of the safety advice given;
- Choose an ATV with enough power for the work you want it to do. four-wheel driver will give better traction and mobility and may provide a margin of safety;
- Choose a safe route;
- Be aware that increased speed greatly increases the risk of instability and risk of and overturn;

Training

Train everyone who has to use an ATV whether with mounted or trailed equipment or as a solo machine. The training should emphasize the factors affecting stability, the need for care and concentration, and how to recognize the conditions which may affect the safety of operation. It is important for trainees to familiarize themselves with the handling and control of the machine on level open ground before tackling rough hill terrain. Suitable training courses are run by bodies such as ATV Landbase and the forestry Authority.

Helmets

Wear head protection which protects the head and neck. Helmets are suitable. Some users find open faced helmets more suitable than full face helmets.



This symbol means **WARNING** or **CAUTION** Personal safety or damage will be at risk if these instructions are ignored. Most accidents are caused by neglect of carelessness; Avoid needless accidents by following the safety precautions listed below.

2


IN THE INTEREST OF SAFETY:DO NOT_____

1. DO NOT- Operate the mower without all the correct guards fitted.
2. DO NOT- Alter engine settings unless stated by Engine manufacturer.
3. DO NOT- Touch any moving or rotating parts, during working conditions
4. DO NOT- Stop the engine immediately after heavy use, (See section 5.6)
5. DO NOT- Operate the mower without suitable ear and eye protection
6. DO NOT- Allow passengers.
7. DO NOT- Leave machine unattended while operating
8. DO NOT- Run the engine in an enclosed area, exhaust gases contain Carbon Monoxide and are fatal if inhaled.
9. DO NOT- Operate the mower on excessively steep slopes.
10. DO NOT- Operate the mower unless all safety features are fitted to the mower and are used correctly
11. DO NOT- Operate the mower until you have read and understood the entire operators manual
12. DO NOT- Wear loose fitting clothing, to avoid catching on parts of the machine
13. DO NOT- Try to remove blockages while the engine is running. Ensure engine is stopped and the rotor has finished rotating, before any servicing takes place to your mover.
14. DO NOT- Operate the mower in dark conditions unless suitable artificial light is used.
15. DO NOT- Operate if excessive vibration occurs, stop the machine immediately and view maintenance chart.
16. DO NOT- Climb on the mower.

3

IN THE INTEREST OF SAFETY:DO

1. DO- Follow engine manufactures guideline.
2. DO- Ensure all spectators are a safe distance away when operating.
3. DO- Carry out regular servicing and checks before use.
4. DO- Clear cutting area from potential damaging components.
5. DO- Reduce speeds when working on hillsides or rough terrain
6. DO- Be aware components can be hot after operation
7. DO- Follow any towing guidelines stated by ATV manufacturer.
8. DO- Show some caution when filling the tank with fuel, especially if engine components are hot.
9. DO- Ensure all safety decals are in good condition, replace any that are damaged.
10. DO- Keep hands and feet away from rotating blades
11. DO – Ensure mower is in transport position before transporting from workplace.



KEEP WHEEL NUTS TIGHT

CHECK DAILY

REFER TO THE OPERATORS MANUAL



FOR CORRECT tire INFLATION PRESSURE

OBSERVE TOWING VEHICLE MAX TOWING LIMITS OR TRAILER MAX WEIGHTS

ATTENTION

Your responsibilities before operating this machine are:

- Read understand and follow the safety procedures manual
- Train operators before using & review safety procedures regularly
- Ensure that all guards are in place before operating
- Keep hands, feet, hair and clothing away from all moving parts
- Avoid wearing loose clothing whenever possible
- Maintain as per schedule in the safety procedures. Especially blades and securing hardware, due to hazard they present should any part break loose during operation
- During maintenance, use suitable support stands
- DO NOT allow any persons to ride on the equipment



The above decals should be located on your AT – Flail Mower. If any of the above decals are not located on your AT or are damaged in any way contact for some replacement decals before use.

5

OPERATING INSTRUCTIONS AND ADJUSTMENTS

The AT FLAIL MOWER is designed to give safe and dependable service if operated according to instructions and intended use.

Read and understand this manual before operating the mower, as failure to do so could result in personal injury or equipment damage.



When used with an ATV or compact tractor, ear defenders should be worn. Under normal working conditions a noise level of 83 decibels would be usual, in the case protection is advised.

5.1 INITIAL CHECK


1. Make sure that all nuts, bolts and fittings are securely fixed, and that all packaging materials e.g. wire bands, tape etc have been removed. (Remove tape from the front stone deflectors from the underside of the body)
2. Check there is oil in the engine and petrol in the tank.
3. Check tire pressures.

5.2 DRAWBAR ADJUSTMENT

The drawbar attachment height of the towing vehicle can vary. To accommodate adjustment, a screw link is located beneath the drawbar. This should be lengthened or shortened so that the cutting deck is horizontal to level ground. (This ensures a better cutting efficiency)

TO ADJUST

1. Unlock the locking nut (A)
2. Lengthen the link to lower the front of the deck or shorten to raise the deck.
3. Once the deck is level, re-tighten locking nut (A).



QUICK OFFSET DRAWBAR

Unlock the nut and screw slide the drawbar to the desired position and release the screw into the securing hole then lock the nut, as shown.



5.3 MOWER CUTTING HEIGHT

The main cutting height adjustment is achieved by using the screw jack, to raise or lower the cutting deck as necessary.

CUTTING HEIGHT ADJUSTMENT:

****When the wheel are fitted in the rear DO NOT USE THE 2 SRPINGS****

Turn the handle to raise or lower as necessary.



5.4 STARTING THE ENGINE

READ AND UNDERSTAND THE ENGINE OPERATORS MANUAL BEFORE USE



Observe all safety precautions; keep hands and feet away from rotor and other moving parts. Keep spectators at a safe distance.

1. Make sure there is a gap between the blades and the ground / crop
2. Select an area clear of loose debris that could be picked up.
3. Set the engine choke, and suitable idling speed with the throttle.
4. Place one foot on top of the deck body to give a firm and balanced position. Pull the starter cord firmly, allowing the cord to return to return to the housing slowly (one or two strong pulls should start the engine).
5. After a few seconds warming up at idling speed, move the throttle to the factory pre-set working position to give a normal/working engine R.P.M of 3600 max.

NOTE



If the throttle is altered to increase the engine R.P.M beyond the recommended level, the guarantee may become invalid. In addition to this, cutting efficiency will be reduced, fuel consumption will increase and excessive vibration could be caused, resulting in a potential danger to personnel and damage to components.

ELECTRIC START

Push button electric start engine options can be supplied if required. Simply hitch up the mower, connect the electrical supply plug to the ATV socket and turn the ignition key to start the mover. Observing all the precautions mentioned above in 'Starting the mower'.

REMOTE THROTTLE CONTROL

When a remote throttle control option is fitted, normally to the rear carrier frame of an ATV or other suitable site on the towing vehicle, it gives the operator the facility of controlling the

- If not in use for a long time please disconnect the batterie to extend its lifespan

mower engine from the operating position.

The facility is most beneficial when moving from one cutting site to another close to it, by reducing the engine revs to allow the mower flails to come to rest, no harm will be caused to the mower or ground surface during transport, often over rough or difficult terrain when stones and loose objects may be encountered.

5.5 FORWARD SPEED

The amount of grass or weeds to be cut dictates the forward speed; slow forward speeds give better results in most cases. Ensure you follow the procedure below.

NORMAL FORWARD SPEED (1 kph- very heavy use- 10 kph - very light use)

Start off in the slowest speed possible, ensure the mower is working efficiently with the engine set at maximum RPM and not laboring. (If this is not possible due to very heavy cutting conditions, raise cutting height of blades and be prepared to go over twice with machine set lower on 2nd pass, leave at least 24 hours in between 1st and 2nd cut to allow grass to dry out)

Increase forward speed until the RPM of the engine starts to slow down (This is working the engine too hard for conditions) – slow down, let the engine regain full RPM and go through the same process but stop short of speed which made engine labor previously. It is important always to listen to note of engine to ensure engine and mower are working efficiently, slow down or stop once engine starts to labor.

FAILURE TO DO THIS WILL RESULT IN CLUTCH SLIP AND ULTIMATELY SEVERE DAMAGE TO THE CLUTCH AND DRIVE BELTS.



When moving from normal working conditions to heavier cutting, it may be evident that the engine dies down and loses revs. SLOW DOWN IMMEDIATELY to allow the engine revs to build up again to normal working speed. Follow the procedure detailed above in "Normal Forward Speed". Expected forward speed will be much lower in heavy conditions.

**FAILURE TO DO THIS WILL RESULT IN CLUTCH SLIP AND
ULTIMATELY
SEVERE DAMAGE TO THE CLUTCH AND DRIVE BELTS.**

5.6 STOPPING THE MOWER

When stopping the mower after a period of heavy use. Run the machine at half working speed in a stationary position, for at least 4 minutes, to allow the drive belts to cool down.

1. Show caution to hot parts e.g. engine exhaust, belts etc after engine is switched off.
2. Ensure the mower drawbar has been adjusted to allow the mower to run directly behind the towing vehicle and is not in an offset position
3. When the mower has cooled down (Min 1 hr after last used) Ensure all grass has been removed from engine cooling fins, drive belt area, and rotors before operating again.

5.7 TRANSPORT POSITION

When the mower is being moved from one site to another it is advisable to raise the deck to the highest position (Transport position, See section 5.3 "Mower cutting height")

The engine must be stopped and the blades at a standstill before adjusting to the transport position.

Remove any crop debris from the deck before leaving the field.

Never move from one site to another with the engine running.

Please note the AT – Flail Mower is not road legal, and should not be used on public roadways

5.8 ANTI-SCALPING ROLLER/SIDE SKIDS

The main purpose of the anti scalping roller is to prevent damage .If a wheel drops into a hole, or there is uneven ground between the wheels, the roller takes the weight of the mower, avoiding the flails scalping the ground;combined with the side skids the mower provides good protection to the rotor.

The anti scalping roller has the added advantage of-enabling curb side grass to be cut with no difficulty, by allowing the wheel to hang over the curb edge.

The factor pre-set position of the anti scalping roller and side skids are suitable for most situations.

However, if the mover is used in rough conditions or regularly in heavy crops, the roller and side skids should be lowered, to increase the clearance between the flail and the ground when the roller comes into use.

In circumstances where the mower is being used as a “Finishing Mower” and a striped appearance is desired, the roller can be set down using the various hole positions to give the required cutting height, then the wheels can be lifted clear of the ground.

TO ADJUST THE ROLLER:

Slacken pivot bolt “A”.

Slacken and remove bolt

“B”(Repeat for both ends of the roller)


Select another hole and

Replace bolt “B”. Tighten bolts “A” and “B”

TO ADJUST THE SIDE SKIDS:

Remove the bolt at the

Front of the skid and the rear of the skid (show as “C”) Select new setting, replace the bolts and tighten. Repeat for the opposite skid; always ensure both skids are set to



6

MAINTENANCE

Maintenance Schedule				
Maintenance Operation:	Hourly	Daily	Weekly	Seasonal
Engine (See Engine manufacturers manual)	•	•	•	•
Remove excess crop gathered on deck	•	•	•	•
Remove excess crop wrapped around rotor ends	•	•	•	•
Visual check to ensure nothings loose		•	•	•
Grease Height Adjuster		•	•	•
Grease Rear Roller		•	•	•
Grease Rotor Bearings		•	•	•
tire Pressures			•	•
Drive belt inspection			•	•
Rotor Bearing inspection			•	•
Wheel bearing inspection			•	•
Oil 50 mm coupling			•	•
Swivel hitch Bush Wear			•	•
Check All Fasteners are tight and intact			•	•
Safety Chain Guard inspection			•	•
Safety Decals intact			•	•
Safety Guards Intact			•	•
Check Blade wear / condition				•
Check Metal Fatigue				•
Clutch Wear / Function				•

6.1 ENGINE


Refer to engine manufacturers manual, for servicing and maintenance of the engine.

6.2 EXCESS CROP BUILD UP

Remove all crop deposits from the deck, and engine area. Build up of crop deposits could result in heat build and fires

Disconnect the spark plug lead.

Remove any crop that is wrapped around the end of the rotor (A) or on the underside of the deck. Raise the deck to its max height to assist access to the rotor shaft.



6.3 VISUAL CHECK

Make a visual check around the mower, check for missing / loose parts or damaged / worn components. All-faults must be either repaired or replaced. Check and tighten all nuts and bolts prior to each use. Lube all moving parts before each use as well.

6.4 TIRE PRESSURES


DO NOT exceed recommended type pressures			
22×1100	-8		7 – 10 PSI
16.5×6.50	-8		28 PSI (Max)

6.5 ROTOR BEARING INSPECTION

Rotate rotor shaft by hand and feel for any roughness in the bearings. Also try to pull the shaft from side to side to see if any movement is found. If symptoms persist strip down the rotor-housing unit and inspect bearings.

6.6 WHEEL BEARING INSPECTION

Jack one side of the mower body up, so the wheel is just off the ground. Rotate the wheel by hand, and check the wheel alignment. To check the bearing, try to move the wheel from left to right and feel for any play in the bearings (A), ensure the wheel-locating bolt is tight before you start and follow any jacking procedures. If any play is found remove the wheel and



6.7 OIL 50 mm COUPLING/BUSH WEAR

Check coupling for signs of damage or wear, swivel the coupling 36. degrees and check that the bushes are not too worn. Replace any worn or damaged parts.

Oil the coupling regularly as shown below.

6.8 GENERAL INSPECTION

Check the mower to ensure all fasteners are tight and all safety guards / chains are intact and fitted securely. Check all safety-warning decals, Replace any defective guards or damaged decals.

6.9 ROTOR FLAIL MAINTENANCE

The AT range has “Rock” knives designed to last a long time. The standard knives are double edged for even longer life. However, when breaking or losing a knife, it is important to replace it immediately. Failure to do this can cause serious unbalancing problems. (Always use spare parts)

At the time of replacement, the opposite knife on the rotor should be checked for wear. If it is partially or well worn then it should be changed to maintain an accurate weight balance.

When the first cutting edge is becoming blunt, the whole set of flails should be turned around. (Using blunt knives will reduce the cutting efficiency and increase fuel consumption).

Replacing or reversing the knives follows this simple procedure:

- (A) Ensure mower engine has stopped and the knives have stopped rotating. Switch off the fuel tap and let the machine cool down for 5 minutes. Remove the spark plug to ensure the engine cannot be started.
- (B) Raise the mower to its max cutting height.
- (C) Carefully raise the drawbar to an incline position, so that height adjuster bar at the rear of the mower takes the weight. NB; Do not attempt this with the wheels behind version; raise the front jack to its max height.
- (D) Slacken and take out the shackle bolt.
- (E) Replace or turn around blades (Note the direction of rotation)
- (F) Replace shackle bolt securely, but still allowing the shackle to swing on the fixing bush.

NOTE:

Never use cracked or repaired shackles when replacing knives. If the shackle fixing has become damaged or worn, replace with new parts




For repairs beyond the minor adjustments listed above, contact your local dealer or contact.

Your ATV120 Flail accepts only EF-EFG and EF Mulcher Blades series


Flail Mower Blades

1. EF & EFG Grass Blades - Suitable for field grass mowing.
2. EF Mulcher Blades - Suitable for grass or light brush. May be sharpened and used for lawn grooming.
3. EFG Hammer Blades - Suitable for mowing and mulching
Grass & Brush, up to 2" diameter material.
4. EFGC Grass Blades - Suitable for field grass mowing.
5. EFGC Hammer Blades - Suitable for mowing and mulching
Grass & Brush, up to 3" diameter material.









ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120. 003A	MAIN BODY, ASSEMBLY	1	AT120
	AT145. 003A	MAIN BODY, ASSEMBLY	1	AT145
2	AT120. 002	TOW BAR, ASSEMBLY	1	AT120
	AT145. 002	TOW BAR, ASSEMBLY	1	AT145
3	AT120. 005	WHEEL, ASSEMBLY	1	AT120
	AT145. 005	WHEEL, ASSEMBLY	1	AT145
4	AT120. 004	ADJUSTABLE DEVICE, ASSEMBLY	1	
5	AT120. 103	TENSION SPRING	2	
6	W001	SUPPORTING WHEEL, ASSEMBLY	1	OPTIONAL






ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120.015	TOW BAR, WELDMENT	1	
2	AT120.014	LINKAGE ROD, WELDMENT	1	
3	AT120.105	BUSHING	2	
4	AT120.016	LINKAGE FRAME, WELDMENT	1	
5	AT120.106	PIN	1	
6	RP 3.2	R-PIN 3.2	1	
7	GB5782-M16x65	BOLT M16x65	2	
8	GB889.1-M16	LOCK NUT M16	3	
9	GB5782-M16x80	BOLT M16x80	1	
10	AT120.108	HINGE PIN	1	
11	GB91-5x30	COTTER 5x30	2	
12	GB97.1-18	PLAIN WASHER 18	2	
13	AT120.017	ADJUSTABLE SCREW, SET	1	
14	QT50	COUPLING 50	1	
15	GB5782-M12x65	BOLT M12x65	2	
16	GB889.1-M12	LOCK NUT M12	2	





ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120.018A	DECK, WELDMENT	1	AT120
	AT145.018A	DECK, WELDMENT	1	AT145
2	AT120.006	ROTOR, ASSEMBLY	1	AT120
	AT145.006	ROTOR, ASSEMBLY	1	AT145
3	AT120.007	ROLLER, ASSEMBLY	1	AT120
	AT145.007	ROLLER, ASSEMBLY	1	AT145
4	AT120.021	LEFT SKID, WELDMENT	1	
5	AT120.022	RIGHT SKID, WELDMENT	1	
6	AT120.008	POWER ASSEMBLY	1	AT120
	AT145.008	POWER ASSEMBLY	1	AT145
7	EFGC125.117	DRIVEN PULLEY	1	AT120
	EFGC125.117A	DRIVEN PULLEY	1	AT145
8	REACH 04-35x60	LOCKING DEVICE 04-35x60	1	
9	GB / T1154-B1050	V-BELT B1050	2	AT120
		V-BELT B1050	3	AT145
10	AT120.009A	BELT TENSIONING DEVICE, ASSEMBLY	1	AT120
	AT145.009A	BELT TENSIONING DEVICE, ASSEMBLY	1	AT145
11	6-DZM-14	BATTERY 6-DZM-14	1	
12	AT120.131	INSULATING PAD	1	
13	AT120.132	COVER, BATTERY	1	
14	AT120.124	CLOSE PLATE	1	
15	GB5782-M10x120	BOLT M10x120	2	
16	AT120.013	SIDE FENDER, WELDMENT	2	
17	AT120.104	PLUG	2	
18	GB1152- M8x1	GREASE NIPPLE M8x1	1	
19	AT120.111	SHAFT, FENDER	1	AT120
	AT145.111	SHAFT, FENDER	1	AT145
20	EFGC125.113	FENDER	12	AT120
	EFGC125.113	FENDER	45	AT145
21	GB5783-M12x30	BOLT M12x30	19	
22	GB93-12	LOCK WASHER 12	9	
23	AT120.011A	LOWER BRACKET, WELDMENT	1	AT120
	AT145.011A	LOWER BRACKET, WELDMENT	1	AT145
24	AT120.101A	LOWER COVER	1	
25	GB889.1-M12	LOCK NUT M12	10	
26	GB91-3.2x16	COTTER 3.2x16	2	
27	GB97.1-10	PLAIN WASHER 10	3	
28	GB97.1-8	PLAIN WASHER 8	4	
29	GB889.1-M8	LOCK NUT M8	4	
30	GB5783-M6x12	BOLT M6x12	2	
31	GB93-6	LOCK WASHER 6	2	
32	GB97.1-6	PLAIN WASHER 6	2	




ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120. 028	OUTER TUBE, WELDMENT	1	
2	AT120. 029	GUIDE SCREW, WELDMENT	1	
3	AT120. 030	INNER TUBE, WELDMENT	1	
4	GB301-51104	BEARING 51104	1	
5	GB276-600104	BEARING 600104	1	
6	AT120. 027	HANDLE, WELDMENT	1	
7	GB70. 1-M8x35	SCREW M8x35	1	
8	GB1152-M8x1	GREASE NIPPLE M8x1	1	
9	AT120. 120	COVER, HANDLE	1	
10	GB5782-M12x65	BOLT M12x65	1	
11	GB97. 1-12	PLAIN WASHER 12	1	
12	GB889. 1-M12	LOCK NUT M12	2	
13	GB5783-M12x40	BOLT M12x40	1	




ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120.031	ROTARY LINER, WELDMENT	2	
2	AT120.032	WHEEL CARRIER, WELDMENT	1	AT120
	AT145.032	WHEEL CARRIER, WELDMENT	1	AT145
3	AT120.005-A	TYRE, ASSEMBLY	2	
4	GB889.1-M20	LOCK NUT M20	2	
5	GB5782-M10x110	BOLT M10x110	4	
6	GB889.1-M10	LOCK NUT M10	6	
7	GB5782-M10x70	BOLT M10x70	2	





ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120. 033	AXLE, WELDMENT	1	
2	GB276-205	BEARING 205	2	
3	16x6. 5-8	TYRE16x6. 5-8, SET	1	
4	AT120. 121	BUSHING	1	
5	GB96-11x34x3	PLAIN WASHER 11x34x3	1	
6	GB93-10	LOCK WASHER 10	1	
7	GB5783-M10x25	BOLT M10x25	1	
8	AT120. 122	CAP	1	





ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120.026	ROTOR SHAFT, WELDMENT	1	AT120
	AT145.026	ROTOR SHAFT, WELDMENT	1	AT145
2	EFGC125.115	BEARING SEAT	2	
3	UC207	BEARING UC207	2	
4	AT120.116	SEAL SEAT	1	AT120
	AT145.118	SEAL SEAT	1	AT145
5	GB13871-55x80x8	SEAL FB55x80x8	1	
6	GB1152- M8x1	GREASE NIPPLE M8x1	1	
7	AT120.119	KNIFE	56	AT120
	AT120.119	KNIFE	64	AT145
8	AT120.118	SPACER	56	AT120
	AT120.118	SPACER	64	AT145
9	GB5782-M12x80	BOLT M12x80	28	AT120
	GB5782-M12x80	BOLT M12x80	32	AT145
10	GB889.1-M12	LOCK NUT M12	28	AT120
	GB889.1-M12	LOCK NUT M12	32	AT145



ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120. 025	ROLLER, WELDMENT	1	AT120
	AT145. 025	ROLLER, WELDMENT	1	AT145
2	AT120. 019	LEFT BRACKET, WELDMENT	1	
3	AT120. 020	RIGHT BRACKET, WELDMENT	1	
4	GB2673-M8x25	SCREW M8x25	8	
5	EFGC125. 107	BEARING SEAT	2	
6	UC205	BEARING UC205	2	
7	GB5783-M12x30	BOLT M12x30	4	
8	GB889. 1-M12	LOCK NUT M12	4	
9	GB1152- M8x1	GREASE NIPPLE M8x1	2	



ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	JF420E	ENGINE JF420E	1	
2	GB1096-6. 3x6. 3x50	KEY B6. 3x6. 3x50	1	
3	AT120. 012	TOP BRACKET, WELDMENT	1	AT120
	AT145. 012	TOP BRACKET, WELDMENT	1	AT145
4	L100B2. 001	CLUTCH ASSEMBLY	1	AT120
	L100B3. 001	CLUTCH ASSEMBLY	1	AT145
5	AT120. 114	BLOCK	1	AT120
	AT145. 117	BLOCK	1	AT145
6	GB93-12	LOCK WASHER 12	1	
7	UNF 7-16-20x1. 5	BOLT UNF7/16-20x1. 5	1	AT120
	UNF 7-16-20x2	BOLT UNF7/16-20x2	1	AT145
8	AT120. 102-1	TOP COVER	1	AT120
	AT145. 102	TOP COVER	1	AT145
9	GB5782-M10x45	BOLT M10x45	4	
10	GB97. 1-10	PLAIN WASHER 10	4	
11	GB889. 1-M10	LOCK NUT M10	4	
12	UNF 5-16-24x1	BOLT 5/16-24x1 UNF	4	
13	GB93-8	LOCK WASHER 8	8	
14	GB97. 1-8	PLAIN WASHER 8	8	
15	GB5783-M8x20	BOLT M8x20	4	



ITEM	PART No.	NAME & SPECIFICATION	QTY.	MODEL
1	AT120. 041	CONNECTING LINK, WELDMENT	1	
2	AT120. 140	SPRING	1	
3	GB889. 1-M12	LOCK NUT M12	1	
4	GB / T96. 2-12×3	PLAIN WASHER 12	1	
5	AT120. 024A	SWING ARM, WELDMENT	1	AT120
	AT145. 024A	SWING ARM, WELDMENT	1	AT145
6	GB893. 1-47	INTERNAL CIRCLIP 47	1	
7	GB276-303	BEARING 303	2	
8	AT120. 115	TENSION PULLEY	1	AT120
	AT145. 115	TENSION PULLEY	1	AT145
9	GB96-8	PLAIN WASHER 8	1	
10	GB93-8	LOCK WASHER 8	1	
11	GB5783-M8x20	BOLT M8x20	1	
12	AT120. 123A	BUSHING	1	
13	GB93-12	LOCK WASHER 12	1	
14	GB / T6170-M12	NUT M12	1	
15	AT120. 141	PLATE	1	
16	GB / T70. 1-M6×12	SCREW M6x12	2	
17	AT120. 142	COVER	1	

Value-Leader Brand 1 Year Warranty

Unless otherwise stated on purchase invoice, Machineire DB warrants to original Purchaser that Value-Leader products are free from major defects in material under normal use and service for a period of 1 Year from the date the product is purchased or shipped, whichever is later. Commercial use 3 Months. Use at address that is not yours, is considered commercial use. Consumable, Expendable, Wear Items (Rubber plastic parts, hydraulic hoses, belts, cables, blades, knives, wedges, teeth, chains, pins, filters, etc.) and cracked hydraulic pumps, bent or broken cylinder rods are not covered under this warranty. Warranty does not cover items that have been modified, damaged by abuse or usage not in accordance with design or maintenance.

Machinerie DB obligation under this warranty is to repair or replace defective upon approval by;Machinerie DB, 1776 route 161 St Valere. Product shall be returned upon request of Machinerie DB. Transportation charges to be prepaid by user.

Gasoline or diesel engines used to powered Value-Leader products are covered by the warranty of the appropriate engine manufacturer Purchaser must look to the engine manufacture for all issues relating to engine operation.

Machinerie DB assumes no responsibility for outside labor.

PERMISSABLE BY APPLICABLE LAW, MACHINERIE DB DISCLAIMS ALL WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, ANY IMPLIED WARRANTIES WITH RESPECT TO THE PRODUCT PURCHASED, WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, MACHINERIE DB EXPRESSLY DISCLAIMS ALL LIABILITY FOR PRODUCT DEFECT OR FAILURE, CLAIMS THAT ARE DUE TO NORMAL WEAR, PRODUCT MISUSE, ABUSE, PRODUCT MODIFICATION, IMPROPER PRODUCT SELECTION, NON-COMPLIANCE WITH ANY CODES, OR MISAPPROPRIATION. MACHINERIE DB MAKES NO WARRANTIES TO THOSE DEFINED AS "CONSUMERS" IN THE MAGNUSON-MOSS WARRANTY FEDERAL TRADE COMMISION IMPROVEMENTS ACT. THE FOREGOING EXCLUSION OF IMPLIED WARRANTIES DO NOT APPLY TO THE EXTENT PROHIBITED BY LAW. PLEASE REFER TO YOUR LOCAL LAWS FOR ANY SUCH PROHIBITIONS.

THERE SHALL BE NO LIABILITY FOR PRODUCT LIABILITY OR LIABILITY ON THE PART OF MACHINERIE DB FOR ANY GENERAL SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE SALE OR USE OF ANY PRODUCTS SOLD BY MACHINERIE DB OR AN AGENT THEREOF, MACHINERIE DB MAKES NO WARRANTIES, EXPRESS OR IMPLIED, (INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS OF THE PRODUCTS FOR ANY PURPOSE) WITH RESPECT TO THE PRODUCTS COVERED BY THIS AGREEMENT EXCEPT AS IN THIS PARAGRAPH OTHERWISE EXPRESSLY PROVIDED.

THIS IS THE SOLE AND ONLY WARRANTY OF VALUE-LEADER PRODUCTS, NO OTHER WARRANTY IS APPLICABLE, EITHE EXPRESSED OR IMPLIED, IN FACT BY LAW.

This warranty shall not be interpreted to render MachinerieDB, or any authorized agent liable for injury or damages of any kind or nature, direct, consequential, or contingent, to a person or property.

The sole and only remedy in regard to any defective product shall be the repair or replacement thereof as herein provided, Machinerie DB, agent(s) of Machinerie DB shall not be liable for any consequential, special, incidental or punitive damages resulting from or caused by any such defects

Machinerie DB reserves the rights to make improvements in design or changes in specifications at any time, without incurring any obligations to owners of the units previously sold.

